

Stainless Steel Flat Disk Tactile Indicators



Flat Disk

Top of Dome: 25mm
Bottom of Dome: 35mm
Height of Dome: 5mm

Stainless Steel Flat Disk Tactile Indicators manufactured from 316 Marine Grade Stainless Steel chosen for its high resistance to pitting and general corrosion under most environments as well as the high lustre for aesthetic appearance and high slip resistance.

The product is cold forged from one piece of metal, i.e. without welding, to give it the mechanical strength to withstand rough usage. The tactile indicators come with a concentric circle design on the top with a smooth bevelled edge.

Ideal for Marble, Terrazzo, Limestone, Ceramic, Glass and Metals.

Tactile Indicators provide both directional and hazard warnings which can be used internally and externally in situations such as stairways, ramps, escalators, kerbs, car park crossings, railway platforms, passenger wharves, bus stops and overhead hazards.

Stainless Steel Flat Disk – Tactile Indicators

Benefits and Technical Details Stainless Steel Tactile Indicators meet or exceed the performance criteria specified in the following tests or standards:

1. **Testings (Performed by CSIRO)**

AS/NZS 4586 Appendix A *Wet Pendulum 4S W*.
AS/NZS 4586 Appendix D *Oil Wet Ramp test R12*.
AS/NZS 1428.4 *Wet & Dry Luminance Reflectance*.
Dry 25.1/Wet 19.5 Mean Contrast Range 10.8 = 45.5.

2. **Slip Resistance**

AS/NZS 4586:2004 Slip Resistance Ratings with R11 and R12 ratings.

3. **Australian Standards**

Manufactured according to AS/NZS1428.4 2002 (F)

4. **Easy Cleaning**

Washability:

Regular cleaning to remove built up dirt and objects on the Tactile Indicators will ensure continued performance. Vacuuming or brushing with a stiff bristle head (dry or wet) is often enough to keep Tactile Indicators clean.

Observation will determine if cleaning is required however a regular clean every 4 to 6 weeks or after particularly heavy use should ensure correct performance.

Do not use highly alkaline or acidic cleaning agents. The pH of the cleaning agents should be between pH5 and pH12.